



Since 1990

DECCO FIX-IT, DRILL & FILL

Total Wood Floor Repair Kit

DESCRIPTION:

DECCO FIX-IT, DRILL & FILL - Total Wood Floor Repair Kit is a complete repair kit you need to repair: hollow spots, squeaks, end-lifting, delamination, etc. for engineered hardwood floors. Amazon: #1 New Release in Wood Glue. (available for sales at www.amazon.ca & www.amazon.com). Repaired wood floors feel SOLID! No more: "bouncy", "springy", "creaking", "spongy", "popping", "delam" floors!

APPLICATION:

DECCO FIX-IT, DRILL & FILL is used to repair defective installed floors. These floor defects are caused by gluedown flooring adhesives fail to perform, sub-floor not level, installation defects, water damages, wood floor quality creeping due to radiant heat cycling over time. **DECCOBOND 38 Wood Floor Repair Adhesive** is proprietary formulated (NOT your typical white wood glue, yellow wood glue or carpenter glue), solvent free, VOC free, eco-friendly, non-flammable, flows & fills voids easily, non-crystallizing, resilient after cured and remains elastomeric throughout the life of the floor, radiant heated floors compatible.

PREPARATION & COVERAGE:

DECCO FIX-IT, DRILL & FILL is supplied ready to use. Each kit comprises: **DECCOBOND 38 Wood Floor Repair Adhesive**, 500 ml, re-usable heavy duty syringe, high strength steel drill bit, dowels, center punch, vinyl gloves. 5-Easy steps to repair for flooring professionals & DIY. Huge cost saving! No need to remove & replace loose & hollow floors.



FIX-IT Drill & Fill

Superior Quality. Revolutionary.

- Total Wood Floor Repair Kit
- 5-Easy Steps
- For Professional & DIY
- Huge Cost Saving
- Repaired Floors Feel SOLID!

Applications

- Hollow Spots
- Squeaks
- End-lifting
- Delamination

* Trademark of Tenco Westech Polymers Inc.

5 EASY STEPS

INSTRUCTION:

1. Locate area with hollow spots suspected of delamination ("delam") of wood floor to plywood/OSB/concrete subfloor. Dropping a golf ball on suspected delam areas and check on bounce back sound differences will indicate location. Mark out suspected areas with painter's release tapes.
 2. Use center punch to mark out spots that need to drill holes. Drill holes at marked spots on floor and ensure it reaches all the way through to the bottom of the wood floor. Vacuum debris from each hole.
 3. Stir **DECCOBOND 38 Wood Floor Repair Adhesive**. Fix the large bore Suction Tip (ST) to syringe the **DECCOBOND 38 Wood Floor Repair Adhesive** from the container. Hold in positive pressure & replace tip with Injection Tip (IT).
 4. Inject **DECCOBOND 38 Wood Floor Repair Adhesive** into hole. If more than one hole is drilled in delam areas, adhesive will exude in the other hole. Fill adhesive in all drilled holes including holes with exuding adhesive.
 5. Once voids are filled, use dowels to plug the holes. Dowels are provided with larger diameter; use a sharp blade to taper to good fit. Center punch can be used to assist in a good plug insert.
- After plugging, wipe floor with damp cloth & water before adhesive dry up. Dried adhesive film makes cleaning difficult. Top off the plugged holes with wood putty to match the color of the wood floor.

IMPORTANT: To ensure that the injection tip and suction tip do not have heavy built up of adhesive after repeated use, immerse tips in large cup of water immediately after each use. Flush the syringe tips with water repeatedly to get a clean tip & save for reuse.

Each Kit comprises:

- 1 x 500 ml. (1.1 Pint) **DECCOBOND 38 Wood Floor Repair Adhesive** (D 38)
- 1 x 50 ml. Heavy Duty Syringe c/w replacement washers. (S 50)
- 2 x Tips : 1 x Injection Tip (IT 12) & 1 x Suction Tip (ST 8)
- 1 x Drill Bit $\frac{1}{8}$ " bore (DB 8)
- 4 x Dowels (DW 4)
- 1 x Center Punch for marking (CP 1)
- 1 x pair Vinyl Gloves (VG 1)

All items in the kit are available for sale separately.

DECCOBOND 38 Wood Floor Repair Adhesive (D 38) are available in two sizes: 500 ml. (1.1 Pint) & 4.0 L (1.04 US Gal) jug.

Assembled with Canadian Adhesives & Imported Components.



STORAGE:

DECCOBOND 38 Wood Floor Repair Adhesive is stable. Stores well for at least 24 months at room temperature of 20° C. Do not store next to heaters or very high temperature of 30° C or more. **KEEP FROM FREEZING.**



TENCO WESTECH POLYMERS INC.
160-6333 Graybar Road, Richmond, B.C.
Canada V6W 0C4 t 604-276-8538